



#### **CABINET PARTS**



### **CABINET PARTS**

Illus. Part No. No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus No.		DESCRIPTION
W10054090 W10054070 Following May DO-IT-YOU	Quick Start Use & Care Guide  y Be Purchased  JRSELF	12 13 14 15	342055 8578538 3394083 3392100	Seal, Door Screw, 8–18 x 3/64 Restrainer, Belt Clip, Front Panel (2) Foot, Dryer Foot–Optional (Extended Length Package of 2)	29 30 31 33 35 36 37 38	8539897 8533974 8572983 8565020 8565038 8575033	Bracket, Switch Belt–Switch Jumper Screw Ground Strike, Door Door, Inner Door Outer Handle, Door Seal, Front Panel
LIT677818		17	279318	(Not Included) Terminal, Tinned & Brass (3)	39		Terminal Block Kit (For Terminal Block)
3 693995 4 W10007520 5 W10110241 6 8576625 7 8558830 8 3404413 9 8568303 10 3978977	Screw, 10–16 x 1/2 Screw, 8–18 x 3/8 Clip, Ground (2) Cover, Block Lock–Top Front (2) Panel, Rear Plug–Hole Locator, Snap Down Door Switch Assembly Retainer, Idler	18 19 20 21 22 23 24 25 26 27	3387374 8565029 8566208 660658 8572982 8578560	(Includes Illus. 39) Cabinet Pal-Nut (4) Spring, Idler Panel, Front Switch Assembly Clamp, Motor Catch, Door Assembly Hole-Plug (Cabinet Base) Screw, 10–16 x 1/2	40 41 42 43 44 45 46 47 48 49	3397659 8547174 8547168 8547166 W10002600 8578565 8566152 238088	Screw, 10–32 x 5/8 Block, Terminal Pulley Assembly Belt, Drive Base, Motor Bolt, 6–20 x 1 1/4 Pulley, 60 HZ Motor Assembly 60 HZ. Hinge, Top (2) Filler–Door

# **TOP AND CONSOLE PARTS**




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

#### **TOP AND CONSOLE PARTS**

Illus	. Part	
No.	No.	DESCRIPTION
		_
1	W10106830	
2	8558863	Bracket, Console
4	8563976	User Interface
5 7	W10110326	Panel, Console
	8564265	Cover, Rear
8 9	W10003770 8574957	Screw, 6–19 x 3/64
10	8572270	Knob, Assembly Assembly,
10	0312210	Lint Screen
11	W10044320	Cover, Lint
	W10044020	Screen
12	W10044470	Hinge, R.H.
	W10044480	Hinge, L.H.
13	W10001580	Screw, 8–18 x 5/8
15	3395683	Connector
		(Motor)
16	8565021	Тор
17	W10074280	Control,
		Electronic
18	3394427	Clip-Harness
19	8563853	Bracket,
- 4		Machine Controller
21	337686	
22 23	8558853	
25 25	8299915 3936144	Harness Wiring Connector
26 26	94614	Terminal
27	3397269	Connector, Timer
21	3331203	Connector, Timer

# **BULKHEAD PARTS**



# **BULKHEAD PARTS**

IIIus No.	. Part No.	DESCRIPTION
1	8544805	Lint Chute
		Assembly
2 3 4	487909	Screw, 8-15 x 1/2
3	3387459	Washer-Support
4	347139	Seal, Lint
5	90767	Chute Screw, 8–18 x 3/8
6	8573836	Shield, Exhaust
8	8577891	Thermostat,
J	0077001	HI-Limit
9	3977393	Thermal Cut-Off
		(Includes
		Illus. 15)
10	694089	Wheel, Blower
		(Includes
4.4	0.577000	Illus. 22)
11 12	8577230 8546149	Housing, Blower
13	343641	Clip-Heater Box Screw, 10-16 x 1/2
14	8544801	Box, Heater
15	W10053480	Bracket,
		Lint Chute
16	3977373	Bracket, Drum
		Light
17	8565582	Element, Heater
18	8544813	Seal
19	279457	Wire Kit, Terminal (For Heater
		Element Wiring
		Harness Repair)
20	489463	Screw, 8–18 x 5/8
22	3406124	Bulb
23	8558890	Bulkhead, Front
24	3402841	Lens, Drum Light
25	690997	Ring Tri
26	8575325	Shaft, (L.H.)
27	8575324	Shaft, (R.H.)
28 29	8536973 W10001120	Roller, Support Nut, 3/8–16
30	8576468	Assembly, Sensor
31	8557242	Bulkhead, Rear
32	3934666	Nut 3/8–16 (R.H.)
35	8557277	Seal Drum (2)
36	97787	Screw, 11-16 x 3/4
37	8557272	Drum, Assembly
38	8565688	Baffle, Drum (2)
39	3403634	Socket Assembly
40	8577274	Thermistor
41	8544810	Collar, Lint Chute

# **OPTIONAL PARTS (NOT INCLUDED)**

For Model: WED6200SW0 (WHITE)

Illus. Part

No. No. DESCRIPTION

#### **ACCESSORY PARTS**

279948 Kit, Dryer Repair W10071550 Dry Rack 8522199 Kit, Dryer Vent Testing

#### PAINT, TOUCH-UP (1/2oz.)

72017 White

# PAINT, PRESSURIZED SPRAY (12 oz.)

350930 White 350938 Primer, Gray

#### PAINT, BULK (1 qt.)

799344 White (Uncut)